

Pro's Choice Super Sub-Floor Underlayment Panels Installation Recommendations

Acclimation

24 to 48 hours in the room environment in which the panels will be installed.

Installation Recommendations

- Inspect panels for surface and edge damage prior to installation.
- Install the long dimension of the panel perpendicular to or (across) the floor joists for maximum rigidity.
- Make sure panel seams offset any original sub-floor panel seam by at least 6".
- Stagger panels, so that four corners do not meet. Offset panel joints by at least 16".
- Leave a minimum 1/8" gap around the perimeter walls.
- Butt all panels, but do not force sheets into place.
- Fasten panels securely to a structurally sound, smooth clean and dry original sub-floor with 18 gauge staples with chiseled ends and/or 12 gauge galvanized ring groove s hank nails.
- Make sure fasteners do not project through the original sub-floor or into the floor joists.
- Position fasteners in the field on the 4" inch centers X markings.
- Attach fasteners 1 1/2" apart and 3/8" from edge.
- Set fasteners flush or slightly below the panel surface.
- Fill all edge joints and other surface depressions patch and sand smooth. Make sure patch is FULLY DRY before installing the finished floor.
- The finished floor should be installed immediately after **Pro's Choice Super Sub-Floor Underlayment Panels** to prevent job site influenced damage.